

# NUMBERED ELBOW

## INSTALLATION



REQUIRED TOOLS:



GLOVES



SAFETY GLASSES



SIZING CHART



BANDING



and/or SCREWS



SILICONE

**1**

Identify proper size using sizing chart provided by supplier or [www.idealproducts.ca](http://www.idealproducts.ca)

**2**

Take out of box and identify outside (with lip) & inside (with bead) pieces. No need to bead or crimp.

**3**

pieces should overlap creating a "water ingress prevention channel"

Install inside (with bead) piece on insulated elbow throat first (a) then heel (b). Outside should be ovetop of the inners in both the heel and throat while keeping the bead on the inside throughout. Seams should be in watershed fashion.

**4**

Fasten as per specifications with strapping and/or screws with neo-bond washers. Finish seams with owner approved sealant.

[CLICK HERE TO VIEW VIDEO INSTRUCTIONS](#)



CAN [1.800.299.0819](tel:18002990819) | USA [1.888.977.7685](tel:18889777685)  
[WWW.IDEALPRODUCTS.CA](http://WWW.IDEALPRODUCTS.CA)

