

# THERMALJACS547®

## INSTALLATION



THERMALJACS547®

REQUIRED TOOLS:



GLOVES



SAFETY GLASSES



UTILITY KNIFE



FILAMENT TAPE /  
TIRE WIRE /  
STRAPPING  
(for insulation)

**Notes:**

- Recommended Strapping: Ideal Products QuickStraps™
- As approved by owner

**1**

Carefully cut open package with utility knife

**2**

Carefully but firmly roll up the first piece and hold for 3-5 seconds until PSA (pressure sensitive adhesive) has reacted and created a bond to form the insulation shell

**3**

Wrap around pipe

**4**

Fasten with QuickStraps™ or owner approved strapping

CLICK HERE OR SCAN QR CODE TO VIEW DATA SHEET



CAN 1.800.299.0819 | USA 1.888.977.7685  
WWW.IDEALPRODUCTS.CA

